

# GRIT: Pro trail handle installation

Have a question? Give us a call at 617-356-8106 or email us at [support@gogrit.us](mailto:support@gogrit.us).

**1**

Use a 4mm Allen key to loosen the four bolts on the Trail Handle receiving clamp.



**2**

Slide the Trail Handle through the inside of the Trail Handle receiving clamp.



**3**

Adjust the Trail Handle to the desired position.



**4**

Retighten the four bolts on the Trail Handle receiving clamp.



**5**

Repeat steps 1-4 for the other Trail Handle.



## **Note:**

If your handles are moving, the four bolts aren't tightened. Reposition your handles and tighten the bolts with your 4mm Allen key.

